

ECE3204 Lecture 8

Finish Op-Amp Design Example

Handouts:

DC Errors: Offset Voltage, Bias Current
Slew Rate Limiting

